thumbsUp!

ARTWORK INFORMATION PANEL

ARTWORK TITLE: WIRELESS CHARGER LIGHT MANUAL

ARTWORK TYPE: ☐ PACKAGING ■ MANUAL ☐ STICKER

MATERIAL: 80gsm

FINISH: -

CUTTER GUIDE SIZE:

PRODUCT CODE: OR-RETHC

BARCODE: 5060491776131 **TYPE:** EAN 13, 80%

CMYK	SPECIFIC PANTONE COLOURS	FOLDING GUIDE	CUTTER GUIDE
		Spot Colour 'Folding'	Spot Colour 'Cutter guide'

FONT LISTING:

	WHERE	WHAT
1.	Product Title	PRESS START
2.	General Text	HELVETICA
3.	Details	HELVETICA
4.	Warnings	HELVETICA

NOTES:

FOLDED MANUAL

DOUBLE SIDED PRINT.

VERSION DATE:

DATE	DESIGNER
05/10/2021	AIDEN MURPHY

APPROVAL:

STAGE	DATE	SIGNATURE	check and tick COPY
DESIGNER	___ / ___ / ____		
COPY	___ / ___ / ____		
MANAGER	___ / ___ / ____		
DIRECTOR	___ / ___ / ____		

PLEASE MAKE SURE ALL FONTS HAVE BEEN OUTLINED, AND ALL IMAGES EMBEDDED.

thumbsUp!

Magnus Brands Limited, Roving, Ma1 4XS, UK

Magnus Brands (EU) Limited Herbert House, 24 Parsonage Rd, Dublin 5, Ireland

Magnus Brands Inc. 19 West 34th Street, 8th Floor New York, NY 10001 - USA

For more product information please visit: www.thumbsup.com

*NOTE: Images and illustrations may differ from actual product.

CMKTCHSLW

MADE IN CHINA · FABRIQUÉ EN CHINE

Compact Kitchen Scale



INSTRUCTIONS

FR

PRODUCT DEMONSTRATION



* Product picture is for reference only, please refer to actual product.
* Please make sure the object is in the effective weighing area when weighing.

LCD

Tare weight
Negative value
Zero weight
Gram
lb:oz Pound:Ounce

* LCD display is indicative only, please refer to actual product.

TO INSTALL OR REPLACE BATTERY

* One 3V CR2032 lithium battery(included)

1.Please slide the battery case off in the direction of the indication mark, push the battery gently inwards, then it will pop out (please use a tool if necessary).

2.Install the battery with positive plate on top.

3.To install the battery cover, aim catch at the groove and push back into place.

OPERATION

1.Put the scale on the flat platform, open to a 90° angle

2.Put the plate on the scale (if necessary);

3.Push ● button to turn the scale on.

4.Start weighing when it shows "zero";

5.Put the object on the scale, then lod shows the weight.

"ZERO" OR "TARE" FUNCTION

To weigh different loads consecutively without removing loads from the scale. Put first load on the scale, get weight reading. Press "●" to reset the lod reading to "0" before adding next load. You can repeat this operation.

Condition 1: "ZERO" Function
When total sum of all loads on scale <4% of scale's max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g).

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment. 0g and meanwhile an icon ○ on the left side of LCD means ZERO Function is activated. Max Weight capacity remains unchanged.



Condition 2: "TARE" Function
When total sum of all loads on scale >4% of scale's Max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g)

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment. 0g and meanwhile an icon TARE on upper left corner of LCD means TARE function is activated. Max. weight capacity is reduced by the total weight added to the scales.

TO CONVERT WEIGHT UNIT

If the scale is with both unit system of metric (g/ml) or Imperial (lb:oz, fl:oz), press "●" button for five seconds to convert units.

AUTO SHUT OFF



Auto shut-off occurs if display shows "0" or shows the same weight reading for about 2 minutes

WARNING INDICATORS

1.When the LCD shows " Lo " indicating low battery. Please replace new battery.

2.When the LCD shows " Err " indicating overload. Please remove item to avoid damage. (Max. weight capacity is indicated on the scale)

CLEANING AND CARE

1.Clean the scale with a slightly damp cloth. Do not immerse the scale in water or use chemical abrasive cleaning agents.

2.All plastic parts should be cleaned immediately after contact with fats, spices, vinegar and strongly flavoured/ colored food. Avoid contact with acids citrus juices.

3.Always use the scale on a hard, flat surface.

4.DO NOT drinke, shake or drop the scale.

5.Treat the scale with care since it is a precise instrument.

6.Put the scale in a cool and dry place.

7.If fail to switch on the scale, please check whether battery is indalled or battery power is low.

8.For family use only. DO NOT use for commercial purpose.

Attention : ne pas ingérer la pile, risque de brûlure chimique. Ce produit contient une pile bouton. Si la pile est avalée, elle peut causer de graves brûlures internes en seulement 2 heures et entraîner la mort. Conserver les piles neuves et usagées hors de portée des enfants. Si le compartiment à piles ne ferme pas correctement, cesser d'utiliser le produit et le tenir hors de portée des enfants. Si vous pensez que des piles ont été ingérées ou insérées dans une partie du corps, veuillez consulter un médecin immédiatement.

IT

PRODUCT DEMONSTRATION



* Product picture is for reference only, please refer to actual product.
* Please make sure the object is in the effective weighing area when weighing.

LCD

Tare weight
Negative value
Zero weight
Gram
lb:oz Pound:Ounce

* LCD display is indicative only, please refer to actual product.

TO INSTALL OR REPLACE BATTERY

* One 3V CR2032 lithium battery(included)

1.Please slide the battery case off in the direction of the indication mark, push the battery gently inwards, then it will pop out (please use a tool if necessary).

2.Install the battery with positive plate on top.

3.To install the battery cover, aim catch at the groove and push back into place.

OPERATION

1.Put the scale on the flat platform, open to a 90° angle

2.Put the plate on the scale (if necessary);

3.Push ● button to turn the scale on.

4.Start weighing when it shows "zero";

5.Put the object on the scale, then lod shows the weight.

"ZERO" OR "TARE" FUNCTION



To weigh different loads consecutively without removing loads from the scale. Put first load on the scale, get weight reading. Press "●" to reset the lod reading to "0" before adding next load. You can repeat this operation.

Condition 1: "ZERO" Function
When total sum of all loads on scale <4% of scale's max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g).

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment. 0g and meanwhile an icon ○ on the left side of LCD means ZERO Function is activated. Max Weight capacity remains unchanged.



Condition 2: "TARE" Function
When total sum of all loads on scale >4% of scale's Max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g)

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment, 0g and meanwhile an icon TARE on upper left corner of LCD means TARE function is activated. Max. weight capacity is reduced by the total weight added to the scales.

TO CONVERT WEIGHT UNIT

If the scale is with both unit system of metric (g/ml) or Imperial (lb:oz, fl:oz), press "●" button for five seconds to convert units.

AUTO SHUT OFF



Auto shut-off occurs if display shows "0" or shows the same weight reading for about 2 minutes

WARNING INDICATORS

1.When the LCD shows " Lo " indicating low battery. Please replace new battery.

2.When the LCD shows " Err " indicating overload. Please remove item to avoid damage. (Max. weight capacity is indicated on the scale)

CLEANING AND CARE

1.Clean the scale with a slightly damp cloth. Do not immerse the scale in water or use chemical/ abrasive cleaning agents.

2.All plastic parts should be cleaned immediately after contact with fats, spices, vinegar and strongly flavoured/ colored food. Avoid contact with acids citrus juices.

3.Always use the scale on a hard, flat surface.

4.DO NOT drinke, shake or drop the scale.

5.Treat the scale with care since it is a precise instrument.

6.Put the scale in a cool and dry place.

7.If fail to switch on the scale, please check whether battery is indalled or battery power is low.

8.For family use only. DO NOT use for commercial purpose.

Attenzione. Non ingerire la batteria, pericolo di ustioni chimiche. Questo prodotto contiene pile a bottone. Se la pila viene ingerita, può provocare gravi ustioni interne in soli 2 ore e può portare alla morte. Tenere le batterie nuove e usate fuori dalla portata dei bambini. Se il vano batteria non si chiude saldamente, interrompere l'uso del prodotto e tenerlo fuori dalla portata dei bambini. Se si ritiene che le batterie possano essere state ingerite o collocate all'interno di una parte del corpo, consultare immediatamente un medico.

EN

PRODUCT DEMONSTRATION



* Product picture is for reference only, please refer to actual product.
* Please make sure the object is in the effective weighing area when weighing.

LCD

Tare weight
Negative value
Zero weight
Gram
lb:oz Pound:Ounce

* LCD display is indicative only, please refer to actual product.

TO INSTALL OR REPLACE BATTERY

* One 3V CR2032 lithium battery(included)

1.Please slide the battery case off in the direction of the indication mark, push the battery gently inwards, then it will pop out (please use a tool if necessary).

2.Install the battery with positive plate on top.

3.To install the battery cover, aim catch at the groove and push back into place.

OPERATION

1.Put the scale on the flat platform, open to a 90° angle

2.Put the plate on the scale (if necessary);

3.Push ● button to turn the scale on.

4.Start weighing when it shows "zero";

5.Put the object on the scale, then lod shows the weight.

"ZERO" OR "TARE" FUNCTION



To weigh different loads consecutively without removing loads from the scale. Put first load on the scale, get weight reading. Press "●" to reset the lod reading to "0" before adding next load. You can repeat this operation.

Condition 1: "ZERO" Function
When total sum of all loads on scale <4% of scale's max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g).

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment. 0g and meanwhile an icon ○ on the left side of LCD means ZERO Function is activated. Max Weight capacity remains unchanged.



Condition 2: "TARE" Function
When total sum of all loads on scale >4% of scale's Max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g)

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment, 0g and meanwhile an icon TARE on upper left corner of LCD means TARE function is activated. Max. weight capacity is reduced by the total weight added to the scales.

TO CONVERT WEIGHT UNIT

If the scale is with both unit system of metric (g/ml) or Imperial (lb:oz, fl:oz), press "●" button for five seconds to convert units.

AUTO SHUT OFF



Auto shut-off occurs if display shows "0" or shows the same weight reading for about 2 minutes

WARNING INDICATORS

1.When the LCD shows " Lo " indicating low battery. Please replace new battery.

2.When the LCD shows " Err " indicating overload. Please remove item to avoid damage. (Max. weight capacity is indicated on the scale)

CLEANING AND CARE

1.Clean the scale with a slightly damp cloth. Do not immerse the scale in water or use chemical/ abrasive cleaning agents.

2.All plastic parts should be cleaned immediately after contact with fats, spices, vinegar and strongly flavoured/ colored food. Avoid contact with acids citrus juices.

3.Always use the scale on a hard, flat surface.

4.DO NOT drinke, shake or drop the scale.

5.Treat the scale with care since it is a precise instrument.

6.Put the scale in a cool and dry place.

7.If fail to switch on the scale, please check whether battery is indalled or battery power is low.

8.For family use only. DO NOT use for commercial purpose.

Caution. Do not ingest battery. Chemical Burn Hazard. This product contains button cell battery. If the cell is swallowed it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely stop using the product and keep it away from children. If you think the batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

DE

PRODUCT DEMONSTRATION



* Product picture is for reference only, please refer to actual product.
* Please make sure the object is in the effective weighing area when weighing.

LCD

Tare weight
Negative value
Zero weight
Gram
lb:oz Pound:Ounce

* LCD display is indicative only, please refer to actual product.

TO INSTALL OR REPLACE BATTERY

* One 3V CR2032 lithium battery(included)

1.Please slide the battery case off in the direction of the indication mark, push the battery gently inwards, then it will pop out (please use a tool if necessary).

2.Install the battery with positive plate on top.

3.To install the battery cover, aim catch at the groove and push back into place.

OPERATION

1.Put the scale on the flat platform, open to a 90° angle

2.Put the plate on the scale (if necessary);

3.Push ● button to turn the scale on.

4.Start weighing when it shows "zero";

5.Put the object on the scale, then lod shows the weight.

"ZERO" OR "TARE" FUNCTION



To weigh different loads consecutively without removing loads from the scale. Put first load on the scale, get weight reading. Press "●" to reset the lod reading to "0" before adding next load. You can repeat this operation.

Condition 1: "ZERO" Function
When total sum of all loads on scale <4% of scale's max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g).

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment. 0g and meanwhile an icon ○ on the left side of LCD means ZERO Function is activated. Max Weight capacity remains unchanged.



Condition 2: "TARE" Function
When total sum of all loads on scale >4% of scale's Max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g)

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment, 0g and meanwhile an icon TARE on upper left corner of LCD means TARE function is activated. Max. weight capacity is reduced by the total weight added to the scales.

TO CONVERT WEIGHT UNIT

If the scale is with both unit system of metric (g/ml) or Imperial (lb:oz, fl:oz), press "●" button for five seconds to convert units.

AUTO SHUT OFF

Auto shut-off occurs if display shows "0" or shows the same weight reading for about 2 minutes

WARNING INDICATORS

1.When the LCD shows " Lo " indicating low battery. Please replace new battery.

2.When the LCD shows " Err " indicating overload. Please remove item to avoid damage. (Max. weight capacity is indicated on the scale)

CLEANING AND CARE

1.Clean the scale with a slightly damp cloth. Do not immerse the scale in water or use chemical/ abrasive cleaning agents.

2.All plastic parts should be cleaned immediately after contact with fats, spices, vinegar and strongly flavoured/ colored food. Avoid contact with acids citrus juices.

3.Always use the scale on a hard, flat surface.

4.DO NOT drinke, shake or drop the scale.

5.Treat the scale with care since it is a precise instrument.

6.Put the scale in a cool and dry place.

7.If fail to switch on the scale, please check whether battery is indalled or battery power is low.

8.For family use only. DO NOT use for commercial purpose.

Advertencia. No ingerir la pila: peligro de quemaduras químicas. Este producto contiene una pila de botón. Si se ingiere la pila, puede causar quemaduras internas graves en solo 2 horas y llegar a provocar la muerte. Mantener las pilas nuevas y usadas fuera del alcance de los niños. Si el compartimento de la pila no cierra bien, deje de usar el producto y manténgalo fuera del alcance de los niños. En caso de sospechar la ingestión de una pila o su introducción en alguna cavidad corporal, pida atención médica de inmediato.

ES

PRODUCT DEMONSTRATION

* Product picture is for reference only, please refer to actual product.
* Please make sure the object is in the effective weighing area when weighing.

LCD

Tare weight
Negative value
Zero weight
Gram
lb:oz Pound:Ounce

* LCD display is indicative only, please refer to actual product.

TO INSTALL OR REPLACE BATTERY

* One 3V CR2032 lithium battery(included)

1.Please slide the battery case off in the direction of the indication mark, push the battery gently inwards, then it will pop out (please use a tool if necessary).

2.Install the battery with positive plate on top.

3.To install the battery cover, aim catch at the groove and push back into place.

OPERATION

1.Put the scale on the flat platform, open to a 90° angle

2.Put the plate on the scale (if necessary);

3.Push ● button to turn the scale on.

4.Start weighing when it shows "zero";

5.Put the object on the scale, then lod shows the weight.

"ZERO" OR "TARE" FUNCTION

To weigh different loads consecutively without removing loads from the scale. Put first load on the scale, get weight reading. Press "●" to reset the lod reading to "0" before adding next load. You can repeat this operation.

Condition 1: "ZERO" Function
When total sum of all loads on scale <4% of scale's max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g).

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment. 0g and meanwhile an icon ○ on the left side of LCD means ZERO Function is activated. Max Weight capacity remains unchanged.



Condition 2: "TARE" Function
When total sum of all loads on scale >4% of scale's Max. weight capacity, (4%=80g when capacity is 2000g; 200g when capacity is 5000g)

LCD will show ---- or 0g each time "●" is pressed, ---- means not stable, please wait for a moment, 0g and meanwhile an icon TARE on upper left corner of LCD means TARE function is activated. Max. weight capacity is reduced by the total weight added to the scales.

TO CONVERT WEIGHT UNIT

If the scale is with both unit system of metric (g/ml) or Imperial (lb:oz, fl:oz), press "●" button for five seconds to convert units.

AUTO SHUT OFF



Auto shut-off occurs if display shows "0" or shows the same weight reading for about 2 minutes

WARNING INDICATORS

1.When the LCD shows " Lo " indicating low battery. Please replace new battery.

2.When the LCD shows " Err " indicating overload. Please remove item to avoid damage. (Max. weight capacity is indicated on the scale)

CLEANING AND CARE

1.Clean the scale with a slightly damp cloth. Do not immerse the scale in water or use chemical/ abrasive cleaning agents.

2.All plastic parts should be cleaned immediately after contact with fats, spices, vinegar and strongly flavoured/ colored food. Avoid contact with acids citrus juices.

3.Always use the scale on a hard, flat surface.

4.DO NOT drinke, shake or drop the scale.

5.Treat the scale with care since it is a precise instrument.

6.Put the scale in a cool and dry place.

7.If fail to switch on the scale, please check whether battery is indalled or battery power is low.

8.For family use only. DO NOT use for commercial purpose.

Avvertenza. Non ingerire la pila: pericolo di ustioni chimiche. Questo prodotto contiene una pila a bottone. Se la pila viene ingerita, può provocare gravi ustioni interne in soli 2 ore e può portare alla morte. Tenere le batterie nuove e usate fuori dalla portata dei bambini. Se il vano batteria non si chiude saldamente, interrompere l'uso del prodotto e tenerlo fuori dalla portata dei bambini. Se si ritiene che le batterie possano essere state ingerite o collocate all'interno di una parte del corpo, consultare immediatamente un medico.

EN: The symbol shown here and, on the product, means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life. The Waste Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to encourage the recycling of products using the appropriate facilities, avoiding landfill and minimising their impact on the environment, treat any hazardous substances and avoid the increase of landfill. When you have no further use for this product, please dispose of it according to your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.

DE: Das hier und auf dem Produkt dargestellte Symbol bedeutet, dass das Produkt als Elektro- oder Elektronikgerät eingestuft wird und am Ende seiner Betriebszeit nicht mit anderen Haushalts- oder Gewerbeabfällen entsorgt werden darf. Die Richtlinie über Elektro- und Elektronik-Altgeräte (WEEE) (2002/96/EG) wurde eingeführt, um das Recycling von Produkten mithilfe der dafür vorgesehenen Einrichtungen anzuregen und die Deponien zu vermeiden. Wenn Sie keine weitere Verwendung für dieses Produkt haben, entsorgen Sie es bitte gemäß den Recyclingverfahren Ihrer lokalen Behörde. Für weitere Informationen kontaktieren Sie bitte Ihre kommunalen Behörden oder den Händler, bei dem das Gerät gekauft wurde.

FR: Le symbole, tel qu'inscrit ici et sur le souris, signifie que le produit est considéré comme étant un équipement électrique ou électronique. Il ne doit, de ce fait, pas être jeté avec les autres déchets ménagers ou commerciaux en fin de vie. La directive relative aux déchets d'équipements électriques et électroniques (DEEE) (2002/96/CE) a été mise en place afin d'améliorer le recyclage des produits grâce à de meilleures techniques de valorisation et de recyclage disponibles, afin de minimiser leur impact sur l'environnement, de traiter les substances dangereuses et de diminuer la mise en décharge. Si vous souhaitez vous débarrasser de ce produit, veuillez le faire en respectant les procédés de recyclage mis en place par votre municipalité. Pour plus d'informations, veuillez contacter votre municipalité ou le distributeur chez qui vous avez acheté le produit.

ES: El símbolo que se muestra aquí y en el producto indica que el producto está clasificado como Aparato Eléctrico o Electrónico y no debe desecharse junto con otros residuos domésticos o comerciales al final de su vida útil. La directiva sobre residuos de aparatos eléctricos y electrónicos (RAEE) (2002/96/CE) se estableció para fomentar el reciclaje de productos mediante las instalaciones adecuadas, evitando vertederos y minimizando para reducir el impacto sobre el medio ambiente, tratar las sustancias peligrosas y evitar el aumento de residuos vertidos. Cuando este producto ya no sirva, deséchelo con arreglo a los procesos de reciclaje de las autoridades locales competentes. Para obtener más información al respecto, se recomienda contactar con las autoridades locales o la tienda donde se adquirió el producto.